





adapter



CHT

A double-headed black arrow pointing from the OpenFOAM component to the libprecice component.



FSI

A double-headed black arrow pointing from the in-house solver component to the libprecice adapter component.